

Power needs to be turned on at the scoreboard, by turning this isolator on.

THE PADLOCK IS NO LONGER USED, SO NO KEY REQUIRED



Laptop is setup in the canteen.

Ensure the power cord, HDMI cord and yellow internet cable are plugged in.

Ensure all powerpoints are turned on for laptop, internet router, HD Over IP unit etc,


Turn on laptop & login
The pin is 'pin123'






Double-click the
'Open Scoreboard Display' icon
to start the software.

THIS SCOREBOARD SOFTWARE MUST BE RESTARTED AFTER EVERY GAME FOR THE APP TO WORK




Select the AFL icon to open the scoring program


THE SCOREBOARD SOFTWARE MUST BE RESTARTED AFTER EVERY GAME FOR THE APP TO WORK




Press the Select Teams tab and then select the HOME team first



Once the AWAY team is selected the controller will automatically move to the AFL tab and the scoreboard will show the 'Match Up' screen



Select the 'Show Game in Progress' button to commence scoring



Scoring can be done on the laptop itself
or via an app

Google Play

https://play.google.com/store/apps/details?id=com.esignsaus.scoreboard24&hl=en_US

Apple

<https://apps.apple.com/au/app/scoreboard-remote/id1630882267>

Open the app and scan the QR code

Scoring can now be done via the app

THE SCOREBOARD SOFTWARE MUST BE RESTARTED AFTER EVERY GAME FOR THE APP TO WORK

The screenshot shows a software interface for game scoring and timer control. On the left, a scoreboard displays 'ST KILDA' and 'GEELONG' with scores of 0 and 0, and a quarter indicator 'Q 1'. The main area features a 'Scoreboard' tab with 'AFL' selected. It includes a 'Qtr 1' dropdown, a timer showing '11:02:06', and input fields for 'ST KILDA' and 'GEELONG' scores, each with four directional arrows. A 'Reset' button and a 'Start' button are visible. A red arrow points from a text box to the arrows on the 'ST KILDA' score field. Another red arrow points from a text box to the 'Start' button. The bottom of the screen shows a Windows taskbar with a search bar and various application icons.

ST KILDA
0 0 0
GEELONG
0 0 0
COME TO TODAY'S C

00:00
Q 1
11:02

ESA

Press up and down on the 4 sets of arrows to change the scores for the home and away teams

Scoreboard AFL Players Team Setup Play Marketing

Animation Setup Close

Qtr 1

11:02:06

ST KILDA
0 0 0

GEELONG
0 0 0


Reset Start

Upcoming Game
Show Game in Progress
Show Player Profile
Show Break Screen


To count-up set the time to 00:00 and press the Start button. To use the timer as a count-down clock input the time to count-down from and then press the Start button.

Game scoring and timer control


Changing which quarter the game is in can also be done on this screen, it is not automatic and has to be done manually



A 'Break Screen' can be shown to allow videos to be played during breaks. Click the 'Show Break Screen' button...



and then select the desired slide show or video to be played on the scoreboard



Once the slide show or video has finished, press the 'Show Game in Progress' button to continue scoring the game